

<b>NEC Codes for AVYCON Recorders</b>	
<b>Device/Group Code</b>	<b>00FF</b>
Function Name	Command Code
REC	0x50
POWER	0x51
0	0x0F
1	0x55
2	0x17
3	0x54
4	0x59
5	0x1B
6	0x58
7	0x5D
8	0x1F
9	0x5C
10	0x4D
Function (FN)	0x4C
Split	0x49
Group	0x0B
Sequence (SEQ)	0x48
Audio	0x45
CHOUTPUT (Switch Resolutions)	0x44
Cursor Up	0x07
Cursor Down	0x13

Cursor Left	0x41
Cursor Right	0x40
Cursor Enter	0x03
Menu	0x5E
Exit	0x1C
<b>PTZ Commands</b>	
PTZ	0x1A
Focus +	0x5A
Focus -	0x56
Iris Open	0x1E
Iris Close	0x16
Zoom +	0x18
Zoom -	0x14
Preset	0x52
Cruise	0x12
Brush (Wiper)	0x11
Lamp (Light)	0x10
Track	0x4E
ESC	0x0E
Schedule	0x0D
Info	0x0C
Play	0x4A
Stop	0x0A
Snapshot	0x09
Search	0x08
Previous Section	0x46
Next Section	0x06

Clip	0x05
Backup	0x04
Rewind (REW)	0x42
Fast Forward (FF)	0x02
Big Picture	0x01
Picture In Picture (PiP)	0x00